

RANGE (R followed by 2 numbers and the letter E (East) or W (West) (i.e., R05E))
 (Range numbers get higher East or West of the Willamette Meridian)

TOWNSHIP (T followed by 2 numbers (i.e., T23))
 (Township numbers get higher in value from South to North)

36	31	32	33	34	35	36	31
1	6	5	4	3	2	1	6
12	7	8	9	10	11	12	7
13	18	17	16	15	14	13	18
24	19	20	21	22	23	24	19
25	30	29	28	27	26	25	30
36	31	32	33	34	35	36	31
1	6						

Section numbers read in a zig-zag pattern
 starting from the top right corner, from 1 - 36

T23R05E

SECTION

NW

QUARTER

NE


QUARTER

SW

QUARTER

SE

QUARTER



Each Township of Public Land Survey is made up of 36 Sections. Each section is roughly 640 acres. Each section is divided up into quarters and each quarter into smaller quarters of each quarter and so on... This is to help locate smaller units down to your parcel. Each quarter of a section is roughly 160 acres and each quarter of a quarter is 40 acres.